

HOUSING BOX FOR CONCRETE 69301 - 69314



B LIGHT
DESIGNED TO PERFECTION




1. INSTALLATION OF THE HOUSING BOX INSTALLATION DE LA BOÎTE DE BOÎTIER

- 1 Make a hole on concrete and pull out the power supply cable.
Faire un trou sur le béton et retirer le câble d'alimentation.

| code | description | dimensions |
|-------|---|-----------------------------|
| 69301 | housing box for concrete: ATRIA MINI, ATLAS MINI, LAPPEN 2 | Ø40xH130 mm / Ø1.57"xH5.12" |
| 69302 | housing box for concrete: ATLAS, BASTER MINI, MEREZ, ATRIA | Ø50xH130 mm / Ø1.97"xH5.12" |
| 69307 | housing box: AGENA | Ø90xH100 mm / Ø3.54"xH3.94" |
| 69309 | housing box for concrete: ATRIA R, ATLAS R | Ø63xH115 mm / Ø2.48"xH4.53" |
| 69312 | housing box for concrete: BASTER, KUADRO | Ø63xH100 mm / Ø2.48"xH3.94" |
| 69314 | housing box for concrete: ATRIA X1 R / ATRIA X1 | Ø90xH140 mm / Ø3.54"xH5.51" |




WALL AND CEILING INSTALLATION
INSTALLATION DE MUR ET DE PLAFOND




FLOOR INSTALLATION
INSTALLATION DE PLANCHER

Make a base with a 20/30 cm of gravel or appropriate drainage system and prepare the cable outlet.
Faire une base avec un gravier de 20/30 cm ou un système de drainage approprié et préparer la sortie du câble.

- 2 Insert the housing box into concrete.
Insérer la boîte de logement dans le béton.



- 3 Fix the housing box, plaster and paint.
Fixer le boîtier, le plâtre et la peinture.



B LIGHT will not consider valid the warranty conditions and will decline any responsibility for damage when the installation is not carried out according to this installation manual.
B LIGHT ne considérera pas les conditions de garantie valables et déclinera toute responsabilité pour les dommages si l'installation n'est pas effectuée conformément à ce manuel d'installation.