




20x20 mm  
0.79"x0.79"


## 1. INSTALLATION OF THE HOUSING BOX - INSTALLATION DE LA BOÎTE DE BOÎTIER

- 1** Make a hole on the concrete and pull out the power supply cable.  
 Faire un trou sur le béton et retirer le câble d'alimentation.




Item Article	Length Longueur
69431	255 mm / 10.04"
69432	505 mm / 19.88"
69433	755 mm / 29.72"
69434	1005 mm / 39.57"
69435	1255 mm / 48.23"
69436	1505 mm / 59.25"
69437	1755 mm / 69.09"
69438	2005 mm / 78.94"
69439	2255 mm / 88.78"
69440	2505 mm / 98.62"
69441	2755 mm / 108.46"
69442	3005 mm / 118.31"

- 2** Make a hole in the housing box for the cable outlet.  
 Faire un trou dans la boîte du boîtier pour la sortie du câble.



- 3** Insert the the housing box.  
 Insérez la boîte du boîtier.



- 4** Cement the housing box evenly with the surface and paint.  
 Ciment la boîte de logement uniformément avec la surface et la peinture.

