




plaster
135 mm
5.31"
kg
0.1 kg
0.2 lbs

1. INSTALLATION - INSTALLATION


EN: INSTALLATION ON PLASTERBOARD WITH REMOTE LED DRIVER
FR: INSTALLATION SUR PLAQUE DE PLÂTRE AVEC TRANSFORMATEUR À DISTANCE




1 EN: Make a hole in the plasterboard.
FR: Faire un trou dans la plaque de plâtre.




2 EN: Insert the housing box in the hole.
FR: installer la boîtier d'encastrement dans le trou.




3 EN: Fix the housing box to the plasterboard by using self-threading screws.
Make sure the head of the screws being completely within the plasterboard.
FR: Fixer la BOÎTIER d'encastrement sur la plaque de plâtre en utilisant vis autotaraudeuses. S'assurer que les têtes des vis soient complètement dans la plaque de plâtre.




4 EN: Plaster and sand.
FR: Reboucher et poncer.



5 EN: Paint.
FR: Peindre.



6 EN: Clean the inside of the housing box.
FR: Nettoyer l'intérieur de la plaque de plâtre.



B LIGHT will not consider valid the warranty conditions and will decline any responsibility for damage when the installation is not carried out according to this installation manual.
B LIGHT ne considérera pas les conditions de garantie valables et déclinera toute responsabilité pour les dommages si l'installation n'est pas effectuée conformément à ce manuel d'installation.